

## KRAIBURG Softbed LongLine

### Prerequisites:




#### concrete surface:

- no holes
- no elevations
- min. 3 % slope

#### mats:


even temperature:  
min. 5° C to max. 30° C  
(store according to initial temperature)




For animal well-being some bedding is necessary to absorb moisture (e.g. soft milled straw or mineral material)

### You will need this:


#### measuring:




#### marking:



#### cutting:




#### drilling and installing:



#### KRAIBURG fixing elements:

- framing plugs  $\varnothing$  10 x 100 mm with
  - hexagon screw (SW 13) - A2
  - washer  $\varnothing$  30 mm - A2
- (fixing elements are part of delivery)

## 1 Placement lines




draw placement lines at the front

**Tip:** use a chalk line

measure from the rear concrete edge


## 2 Lay out foam

**i** Position foam along the placement line 173 cm, allow space for the closure bars on the side edges (see step 5)




#### Tip for deep dividers:

use a wooden board as a limitation at the front edge to avoid slipping of the foam



### 3 Roll out and position rubber covering

roll out rubber covering and position it along the placement line 183 cm




rear concrete edge: min. 3 cm distance!

**!** Cutting out pockets for pillars etc. is not possible!


### 4 Fix

**i** Start from the middle of the roll and fix to the right and to the left.  
Recommendation: work from the head space to avoid slipping of the components.




fix at the front edge through the prefabricated fixing points


**!** Make sure the front edge of the mat is on the marking. Readjust, if necessary.




distance between mat edge and last fixing points: max. 12 cm!




if distance exceeds 12 cm: place an additional fixing point



drill



pound the plastic plugs in flush




fix screws and washers

**!** Fix screws until they are seated evenly fast and are slightly countersunk. **Do not overtighten!**

## 5 Fix side mat edge with closure bar


### A Position bars



left edge with bar


**WELA-L 170** or

**WS-L 170**



contact

**! DO NOT PRESS!**




right edge with bar

**WELA-R 170** or


**WS-R 170**

- rounded off end on the rear edge
- flush with rear mat edge


### B Fix bars



drill



pound the plastic plugs in flush



fix screws and washers until they are seated evenly fast; **do not overtighten!**




#### Tip: avoid slippage:


- fix at one fixing point
- afterwards drill further holes and so on

## 6 Optional: connect two rolls with a middle bar (under a divider)

### A Insert middle bar **WELA-M 170** or **WS-M 170**



2 - 2.5 cm



- rounded off end on the rear edge
- flush with rear mat edge



**! DO NOT PRESS!**

### B Fix bars: see 5 B